

Cowboy Boot Clock



This project requires a 2 3/4" clock insert. I purchased mine at www.woodcraft.com. Item number #152926. The hole for the insert is 2 3/8".



Use a 2 3/8"
Forstner Bit for best
results.

•
If you don't have the
forstner bit cut inside
the circle then sand to
fit.

3/4" Thick

Base 1/2" Thick