



Proud SAW Member

Digital Patterns

Designed by
Steve Good

www.scrollsawworkshop.blogspot.com

Home of Scroll Saw Pattern Printer



Fairy Clock



Requires a 1 7/16" mini Clock insert.

Cut hole with a
1 3/8" forstner bit

1/2" Thick Wood

