



# Digital Patterns

Designed by  
Steve Good

[www.scrollsawworkshop.blogspot.com](http://www.scrollsawworkshop.blogspot.com)

Home of Scroll Saw Pattern Printer  
and the Scroll Saw Key Chain Printer



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

# Hourglass



Finish all pieces before assembly.  
During assembly insert the nipples on the top and bottom of the glass tightly in the holes drilled in the top and bottom wood pieces. Center everything up and make sure the feet at both ends are level so it sit flat. Use rubber band as clamps until the glue dries.

Top/Bottom



Don't over cut the slots. You want the posts to  
fit snug.



$\frac{1}{2}$ " Thick

Cut blanks 9  $\frac{1}{2}$ " long.

