



Digital Patterns

Designed by
Steve Good

www.scrollsawworkshop.blogspot.com

Home of Scroll Saw Pattern Printer



Light House Shadow Box Clock





Use a $1 \frac{3}{8}$ " forstner bit
to cut the hole for a $1 \frac{7}{16}$ "
mini clock insert.



Surround 3/4" thick

1/4" Thick

