

Digital Patterns



Designed by Steve Good

www.scrollsawworkshop.blogspot.com

Home of Scroll Saw Pattern Printer
and the Scroll Saw Key Chain Printer



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

Personal Massager



I recommend using 1.25" wooden toy car wheels. If you don't have those on hand you can use the ones included in the pattern. Make sure the holes in the wheels are drilled slightly larger than the dowell. I used 1/4" dowell stock and redrilled the holes in the wheels the next bit larger.

Drill the handle holes before you cut out the handle. You want the holes centered and aligned. Use the indicator line to drill the holes.

