



Digital Patterns

Designed by
Steve Good

www.scrollsawworkshop.blogspot.com

Home of Scroll Saw Pattern Printer



Mini Desk Clock



Use a 1 3/8" Forstner bit to drill hole for a
1 7/16" mini clock insert

