



# Digital Patterns

Designed by  
Steve Good

[www.scrollsawworkshop.blogspot.com](http://www.scrollsawworkshop.blogspot.com)

Home of Scroll Saw Pattern Printer



## Oval Bowl



Drill the starter holes at 20 degrees.  
Set your scroll saw table at 20 degerrs.  
Start from the center ring and cut each oval.  
Stack and glue the concentric rings to make bowl.

