

SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM

Digital Patterns

Designed by Steve Good



Hundreds of free Patterns
Stencil Printer
Jigsaw Puzzle Templates
DVD's
Key Chain Pattern Printer
Video Tutorials
Reviews
Community Forum and more.

If you would like
to donate click
here. No Paypal
account needed.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

Copyright Steve Good 2017



General Pattern Information

You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the “Page Sizing & Handling” section. Make sure the “Actual Size” is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the “Pages to Print” section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions



Page Sizing & Handling ⓘ

Size

Poster

Multiple

Booklet

☐ Fit

☒ Actual size

☐ Shrink oversized pages

☐ Custom Scale: %

☐ Choose paper source by PDF page size

Pages to Print

☒ All

☐ Current page

☐ Pages

▶ More Options

Smart Phone Passive Amp.





<http://www.heritagewood.com>

 **HERITAGE**
WOOD SPECIALTIES

Special Offer
Free shipping on orders over \$100

Nationally recognized seller of quality
hardwoods for woodworkers across
the US and Canada

Check out the beautiful scroll saw blanks.
www.heritagewood.com






Cut the parts and prepare to sand and glue them together
Glue the sound deflector over the cut out in the front.
Clamp and let the glue dry.






Carefully sand the bottom until you get ~ an 8 to 10 degree angle. If it's easier you can cut this on your table saw.




Beveled Bottom




1/4" Thick



1/4" Thick




1/4" Thick




1/4" Thick
Front



1/8" Thick





1/4" Thick
Back