



Digital Patterns

Designed by Steve Good

www.scrollsawworkshop.blogspot.com

Home of Scroll Saw Pattern Printer



steve@stevedgood.com

Copyright Steve Good 2007

The Dragon



This project requires a 1 7/16" mini clock insert. Use a 1 3/8" forstner bit to cut the hole.



