



Digital Patterns

Designed by
Steve Good

www.scrollsawworkshop.blogspot.com

Home of Scroll Saw Pattern Printer



Time To Run Trophy



1 7/16" mini clock insert.
Use a 1 3/8" Forstner Bit.

