SCROLLS/AWW

Digital Patterns Designed by Steve Good







Hundreds of free Patterns Stencil Printer Jigsaw Puzzle Templates DVD's Key Chain Pattern Printer Video Tutorials Reviews Community Forum and more.






Scan to Donate





Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.



You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.


Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the "Page Sizing & Handling" section. Make sure the "Actual Size" is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the "Pages to Print" section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions





Simple Intarsia Christmas Ornament





You want to select three contrasting woods for this ornament. Try to use the direction of the grain to give some shape to the pieces.



You do not need a lot of contouring or height differences for this ornament. Give it just enough variation for a sense of depth.



I used a #1 blade to cut the pieces. The small blade helps insure there is a good fit of the pieces. Cut carefully at the contact areas of the pieces. You want to avoid gaps if possible

The ribbon and bells need to be three different thicknesses in this order. Tallest, ribbon, right bell, left bell. Because this is such a small project you don't need much difference in height.



Use sandpaper on a flat surface to make the pieces thinner if necessary.

Round over outside edges for some contouring.

Test fit then glue the pieces together. Glue the assembly to the ornament.

Finish as desired.

