SCROLLSAW WORKSH

Digital Patterns Designed by Steve Good







Hundreds of free Patterns Stencil Printer **Jigsaw Puzzle Templates Key Chain Pattern Printer** Video Tutorials Reviews Community Forum and more.

Click to Donate.



Scan to Donate





Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.



You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the "Page Sizing & Handling" section. Make sure the "Actual Size" is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the "Pages to Print" section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions





Basket




Cut f the four weaves and stack in an alternating pattern.



We will use 1/8" wooden dowels for the basket stakes. After you complete cutting the four weave circles, measure their stacked height. Cut 28 dowels to that measurement.

Carefully stack and glue the four weaves to the base.



Insert one of the cut dowels in to each opening in the weave.

Use just a drop of glue on each end of the dowel to hold it in place.

If any of the dowels are higher then the top surface then sand them all flush to the top. Glue on the top rim.



