

SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM



Digital Patterns

Designed by Steve Good



Hundreds of free Patterns
Stencil Printer
Jigsaw Puzzle Templates
DVD's
Key Chain Pattern Printer
Video Tutorials
Reviews
Community Forum and more.

If you would like
to donate click
here. No Paypal
account needed.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

Copyright Steve Good 2019

General Pattern Information



You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the “Page Sizing & Handling” section. Make sure the “Actual Size” is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the “Pages to Print” section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions



Page Sizing & Handling

Size

Poster

Multiple

Booklet

Fit

Actual size

Shrink oversized pages

Custom Scale: %

Choose paper source by PDF page size

Pages to Print


All

Current page

Pages

▶ More Options

Finger Hockey.



Players flip penny to see who goes first.

The first shot is taken from behind the face-off line.

If the player scores a goal then the other player takes the next shot from behind his face-off line.

If the player does not score a goal on his shot then the next player shoots from the position where the penny stopped.


Play continues until one player scores five goals.





Not a scoring goal






Goal scored.





Scoring Peg




1" diameter Hole






Feet glued to bottom location.



1/4" diameter Hole



1" diameter Hole




1/4" Thick

Cut nine 1/2" diameter dowels
to 1 1/4" in length



Drill 1/4" holes.

Cut two 1/4" diameter dowels
to 1 1/2" in length



Drill 1/4" holes.

3/4" Thick board feet.

