SCROLLSAW WORKSH

Digital Patterns Designed by Steve Good







Hundreds of free Patterns Stencil Printer **Jigsaw Puzzle Templates** Key Chain Pattern Printer Video Tutorials Reviews Community Forum and more.

If you would like to donate click here. No Paypal account needed.







You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.


Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the "Page Sizing & Handling" section. Make sure the "Actual Size" is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the "Pages to Print" section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.


Printing Instructions





Lantern





The lantern can use either an battery powered tea light or an electric light kit. This picture show the tea light.



The tea light is inserted with a friction fit. Test your tea light before you cut the hole. Cut is small and sand to a snug fit.





The handle uses a 1/4" diameter dowel. It needs to be 2 3/8" long.



Carefully cut the slots and tabs for a snug fit.





You can find these lighting kits in most craft stores. Here is a link to one on Amazon https://amzn.to/2PARbi8




These simple battery powered tea lights are available at most stores who sell candles,

Do not use a real candle in this project.










Top Cove



Alternative designs.

