SCROLLSAW WORKSH

Digital Patterns Designed by Steve Good







Hundreds of free Patterns Stencil Printer **Jigsaw Puzzle Templates** Key Chain Pattern Printer Video Tutorials Reviews Community Forum and more.

If you would like to donate click here. No Paypal account needed.







You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the "Page Sizing & Handling" section. Make sure the "Actual Size" is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the "Pages to Print" section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions





The Pack Leader Frame for a 4" X 6" picture.



I cut this frame from 1/4" and 1/8" thick Baltic birch plywood.








You want to use the .05" thick acrylic sheet.
You can cut it with an acrylic knife or your table saw
and even the scroll saw. If you have trouble cutting
the acrylic on the scroll saw then sandwich it between
two sheets of plywood.







I used small brass screws to hold the keepers in place.



1/4" Thick

If you cut the slots in the bone feet for a snug fit you don't have to glue them to the frame.


The frame can then be stored flat











1/8" Thick

This is the template for the back picture retainer and for the acrylic sheet.

Buy the .05" sheet of Plaskolite.