

SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM

Digital Patterns

Designed by Steve Good



Hundreds of free Patterns
Stencil Printer
Jigsaw Puzzle Templates
DVD's
Key Chain Pattern Printer
Video Tutorials
Reviews
Community Forum and more.

If you would like
to donate click
here. No Paypal
account needed.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

Copyright Steve Good 2019



General Pattern Information


You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the “Page Sizing & Handling” section. Make sure the “Actual Size” is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the “Pages to Print” section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.


Printing Instructions



Small Puzzle Lock Box








Apply the pattern to the 1/75" X 1.75" X 1.75" wood block.

The sequence of the cuts is important.


Cut off the bottom of the box.






Set the bottom aside.


Cut out the Key. Note that I changed the shape of the key in the finished pattern.





Cut the top of the box. This will cut away part of the pattern.
We have to redraw the wall of the box before we can make
the next cut.

Drill the starter hole for the interior cut.






Cut out the interior of the box. This part is waste and can be discarded.

Here are the four pieces we need.






Glue on the bottom of the box.

Sand to a smooth finish. Round over all the sharp edges.

Apply the finish of your choice.

Note: I changed the shape of the key. The round key rotated inside the cut out and thst did not work well.



1 3/4" X 1 3/4" X 1 3/4" Block

