SCROLLSAWWORKSHOP.BLOGSPOT.COM

Digital Patterns Designed by Steve Good



Hundreds of free Patterns Stencil Printer Jigsaw Puzzle Templates DVD's Key Chain Pattern Printer Video Tutorials Reviews Community Forum and more.

If you would like to donate click here. No Paypal account needed.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

Copyright Steve Good 2016

General Pattern Information

You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the "Page Sizing & Handling" section. Make sure the "Actual Size" is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the "Pages to Print" section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions



Actual size Shrink oversized pages	S <u>i</u> ze	Poster	Multiple	Booklet	
Shrink oversized pages Custom Scale: 100 Choose paper source by PDF page size O All O Current page	🔊 Fit				
Custom Scale: 100 % Choose paper source by PDF page size All Current page	Actual size	◀	•		
Choose paper source by PDF page size All Current page 	Shrink oversized	l pages			
 O Current page 	Custom Scale:	100 %			
© Current page	Choose paper s	ource by PDF page :		rint	
				-	
Pages 1 - 34					
,			Pages	1 - 34	

Woodland Shadow Box



Cut four 7" X 1.5" X 3/4" boards for the frame. Cut a 45 degree miter on each end for form the frame.



Glue the frame together. Cut the backer board 7 inches X 7 inches.



Glue the backer board to the back of the frame.



Print the image on photo paper. The image should be 5.5" X 5.5" when printed. Make sure you check the print dialog as per page two of this book.

Cut the image out.



Prepare the scroll saw pattern on the wood. The wood should be 1/4" Thick.

Cut out all three patterns.



Apply you desired finish to the shadow box before you apply the image. I used a spray laquer.

After it dries apply the image to the inside of the box with spray adhesive.



If you wish to hang the shadow box then attache an hanger to the back of the box.



Glue the tree in first. You don't need to glue it to the image. Just apply glue along the edges.

Next glue in the mother deer.

Finally glue in the baby.



Print on photo paper. Use the print dialog to only print this page on the photo paper. The next pattern page can then be printed separately on regular paper.





