



Digital Patterns

Designed by
Steve Good

www.scrollsawworkshop.blogspot.com


Home of Scroll Saw Pattern Printer
and the Scroll Saw Key Chain Printer



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

Collapsible Basket





To get the basket to open correctly you need to tilt the scroll saw table to the correct angle. For my basket I used 3/4" wood and a #5 blade. The angle worked out to be 4 degrees. If you use a thicker blade or different thickness of wood you will need to change the angle to compensate. Practice on scrap wood of the same thickness until you find the angle that works for you.



Use two screws to attach the handle to the basket. Open the basket to its full height. Set the handle over the basket and mark where the screws should be. Pre-drill and counter sink for the screws. Install the screws and finish with oil.