SCROLLSAW WORKSHOP

WWW SCROLL SAWWORKSHOP BLOGSPOT COM

Digital Patterns

Designed by Steve Good










Hundreds of free Patterns
Stencil Printer
Jigsaw Puzzle Templates
DVD's
Key Chain Pattern Printer
Video Tutorials
Reviews
Community Forum and more.

If you would like to donate click here. No Paypal account needed.







You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.


Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the "Page Sizing & Handling" section. Make sure the "Actual Size" is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the "Pages to Print" section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions





The Dancer.



The Scroll Saw Specialist www.seyco.com





The joints will be pined by small nails. Drill the hole for the knee joint before you cut the slot.


Roundover oaal the joints so you have free movement





Cut the nails to length.

I used two part epoxy to keep the nails in place.



Glue on the feet.







Make the dance platform. Use 1/8" thick wood for the long board so it has some flex. Then glue on the platform. Mine was about 30" long.

