SCROLLSAW WORKSHOP

Digital Patterns Designed by Steve Good







Hundreds of free Patterns Stencil Printer **Jigsaw Puzzle Templates** Key Chain Pattern Printer Video Tutorials Reviews Community Forum and more.

If you would like to donate click here. No Paypal account needed.







You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the "Page Sizing & Handling" section. Make sure the "Actual Size" is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the "Pages to Print" section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions





Multi use hold down as demonstrated by Popular Woodworking






Buy the Magswitches



This jig can be used as a hold down without the Magswitches.
The Magswitches add versatility.

Apply the pattern to 3/4" thick Baltic birch plywood and cut the pattern.





If you plan to use the Magswitches then install them with the appropriate screws.

In the configuration below the Magswitches are used to hold the board to the rip fence like a feather board.





Above it is used as a hold down by clamping it to the table saw fence.

Below it is clamped to the router table fence as a hold down.





In this configuration it is used as a end stop for repeat cuts to the same length.

