SCROLLSAW!

Digital Patterns Designed by Steve Good








Hundreds of free Patterns Stencil Printer **Jigsaw Puzzle Templates** DVD's Key Chain Pattern Printer Video Tutorials Reviews Community Forum and more.





Scan to Donate





Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.



You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.


Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the "Page Sizing & Handling" section. Make sure the "Actual Size" is selected before you hit print.


You also only need to print the page/s you need. After the print dialog opens look for the "Pages to Print" section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions






Gift Tags cut from heavy cardstock paper



We will stack cut several tags at one time from card stock





Wrap the stack in blue painters tape.

Apply the pattern to the top of the taped stack.

Cut the pattern.





Use a #3 or smaller blade for the cleanest cut.



You can cut two layers of cardstock and make a backer for the tags



You can also just use the 1/8" Baltic birch for the tags. You can stack 4 or 5 at a time.



O Christinas

Christinas Simas

ON CONTRACTORY

Christinas Simas

