SCROLLSAW WORKSHOP.BLOGSPOT.COM

Digital Patterns Designed by Steve Good



Hundreds of free Patterns Stencil Printer Jigsaw Puzzle Templates DVD's Key Chain Pattern Printer Video Tutorials Reviews Community Forum and more.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

-

steve@stevedgood.com

Click to Donate.

Pay Pal

General Pattern Information

You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the "Page Sizing & Handling" section. Make sure the "Actual Size" is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the "Pages to Print" section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.


Printing Instructions




S <u>i</u> ze	Poster	Multiple	Booklet		
🔿 Fit					
Actual size	◀	•			
Shrink oversized	d pages				
Custom Scale:	100 %				
Choose paper s	ource by PDF page s	ize Pages to P	int		
		All		-	
		Current	page		
		Pages	1 - 34		


Here is a link to see the animation. https://www.stevedgood.com/spinner.gif





You will need to cut five 1/2" long 1/4" diameter wooden dowels. You need to measure the diameter of the dowel and drill the holes for a snug fit. The only hole that needs to be loose is the center of the circle wheel.






Front

1/8" Thick

Back



Middle