SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM

Digital Patterns

Designed by Steve Good

Hundreds of free Patterns
Stencil Printer
Jigsaw Puzzle Templates
DVD's
Key Chain Pattern Printer
Video Tutorials
Reviews
Community Forum and more.

Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

Copyright Steve Good 2016

General Pattern Information

You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

Printing Instructions

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the “Page Sizing & Handling” section. Make sure the “Actual Size” is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the “Pages to Print” section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.



Guitar Clock on Stand

This project requires a 2 3/4” clock insert.
I purchased mine at www.woodcraft.com.
Item number # 142316. The hole for the
insert is 2 3/8”.

Steve

Parts and Pattern Layout.
I use a small brass hinge for
the stand.



How to install the hinge.

Place the wood parts in position.
Lay the hinge where you want it.
Use an awl to mark the drill points.



Pre-drill the holes with the correct drill bit.





The brass screws are easily stripped. Use a little hand soap on the tip of the screw. This will make it easier to drive the screw.

Use the correct size screw driver to drive the small screws into the wood. If the screw driver is too small or large you will have trouble.

If possible use a 2 3/8 forstner bit to cut the hole for the clock insert. If you do not have this bit it can be cut with the scroll saw. Just be careful not to make the hole too large.

1/2” Thick



1/4” Thick