# SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM

## Digital Patterns

### Designed by Steve Good

Hundreds of free Patterns
Stencil Printer
Jigsaw Puzzle Templates
DVD's
Key Chain Pattern Printer
Video Tutorials
Reviews
Community Forum and more.

If you would like to donate click here. No Paypal account needed.

PayPal Donate Now

Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

Copyright Steve Good 2019

# General Pattern Information

You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

# Printing Instructions

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the “Page Sizing & Handling” section. Make sure the “Actual Size” is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the “Pages to Print” section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.



Welcome to our Home Relief Cut Sign

WELCOME
TO OUR
HOME
Steve

Make all the interior cuts and veining first.

Do test cuts with the blade tilted until you get the relief cut you want. My angle was about 2.3 degrees with a #5 blade and one inch thick wood.



After you have decided on the angle make the relief cut.

Remember that the direction of cut the the direction you tilt the blade determines if the relief will come forward or recess into the wood.



Next you want to cut the outside of the pattern.

It is not necessary to glue the two pieces together. Just push the inner letters forward until they wedge together. People enjoy pushing the piece flat and then pushing it back out.

3/4” Thick

Large pattern on the next page.

3/4” Thick