

SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM

Digital Patterns

Designed by Steve Good



Hundreds of free Patterns
Stencil Printer
Jigsaw Puzzle Templates
DVD's
Key Chain Pattern Printer
Video Tutorials
Reviews
Community Forum and more.

If you would like
to donate click
here. No Paypal
account needed.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

Copyright Steve Good 2017



General Pattern Information


You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the “Page Sizing & Handling” section. Make sure the “Actual Size” is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the “Pages to Print” section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions




Acrylic Angel



HERITAGEWOOD.COM !

Your source for scroll saw ready boards.
www.heritagewood.com




You will need .093 in. Acrylic sheet. I like the Optix the best. It cuts easier with less tear out. I am using Lexan for this project. It's just what I had on hand.


You will also need:

3/4" thick piece of wood.

Spray adhesive.

Spray paint that sticks to plastic. I use the Rustolem 2X.





Do not remove the protective cover from the acrylic. Apply the pattern to the plastic over the protective cover.

You want to use a skip tooth blade for this thin acrylic. Do not use a reverse tooth blade. I used a Pegas #2/0 Skip Tooth





After you complete the cutting remove the BACK protective cover. We will paint the BACK not the front. We want to leave the front glossy.





Use a fine grit sand paper to lightly scuff the **BACK** of the angel. This will let the paint stick better to the plastic.



Paint in 3 or 4 light coats of paint. Remember that we are painting the **BACK** of the angel.



After the paint dries use a clear over coat to protect the paint. I like the Rustoleum 2X clear.




After the clear coat dries remove the front protective cover.

Apply a finish to the wood base and install the angel. If you cut the slot correct you should not need to use glue. The angel should be a snug fit.



.093 in. Thick
Acrylic Sheet



3/4" Thick Wood

