

# SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM

## Digital Patterns

Designed by Steve Good



Hundreds of free Patterns  
Stencil Printer  
Jigsaw Puzzle Templates  
DVD's  
Key Chain Pattern Printer  
Video Tutorials  
Reviews  
Community Forum and more.

If you would like  
to donate click  
here. No Paypal  
account needed.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

Copyright Steve Good 2018



## General Pattern Information


You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at [steve@stevedgood.com](mailto:steve@stevedgood.com)

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the “Page Sizing & Handling” section. Make sure the “Actual Size” is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the “Pages to Print” section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.


## Printing Instructions





Spiral Stacked Basket.





This pattern can be cut without the upper rim ring and the round bottom. If you choose this method you can save the extra piece of wood. I like the round rim and bottom so that is how I will proceed. Apply the pattern using spray adhesive.


Drill the interior entry hole using the smallest bit you have.






I am using a micro bit to conceal the entry holes as much as possible. I am using a #63 bit so I have to use a #3 blade. Don't be concerned if you don't have a micro bit set. Just use a 1/16" drill bit and you will not have too large of a hole to try and sand away.


Small entry holes




#3 blade




Start with the interior ring and cut rings out.








After you cut the last ring you need to decide if you will use the upper round rim and the round bottom. If you choose to use those parts then it's time to cut them out.





If you chose not to use the round bottom you can use the interior cut out as the bottom. I will use the round bottom.








Sand and fuzzies off all the pieces.

I use a small paint brush to apply the glue. Start with the interior ring and work your way up.








Apply glue to the tips. You don't need lots of glue. Try to prevent too much squeeze out of the glue.

We will use a heavy weight to clamp while the glue dries.








Place the weighted clamp on the bowl and let the glue cured for a couple hours.

I finished the bowl with spray acrylic. Several light coats work best.

1/4" Thick





1/4" Thick

