

SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM

Digital Patterns

Designed by Steve Good



Hundreds of free Patterns
Stencil Printer
Jigsaw Puzzle Templates
DVD's
Key Chain Pattern Printer
Video Tutorials
Reviews
Community Forum and more.

If you would like
to donate click
here. No Paypal
account needed.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

Copyright Steve Good 2019

General Pattern Information



You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the “Page Sizing & Handling” section. Make sure the “Actual Size” is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the “Pages to Print” section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions



Page Sizing & Handling ⓘ

Size

Poster

Multiple

Booklet

☐ Fit

☒ Actual size

☐ Shrink oversized pages

☐ Custom Scale: %

☐ Choose paper source by PDF page size

Pages to Print

☒ All

☐ Current page

☐ Pages

▶ More Options






I used a 2 3/8" Forstner bit to cut the hole in the thick part of the clock. You can cut it with the scroll saw if you don't have the bit. Just cut slightly inside the pattern line and sand the hole for a snug fit of the clock insert.


There are two versions of the front plate for the clock. The second version is an easier bird to cut.



1/4" Thick



1/4" Thick
Top



This project requires a 2 3/4" clock insert.
I purchased mine at www.bearwood.com.
The hole for the insert is 2 3/8". I recommend
a forstner bit to cut this hole but
if that is not available cut inside the line with
the scroll saw and then sand to fit the insert.
If you get the hole too large for the clock
insert use electrical tape around the insert.

1/4" Thick

Easier Version

