SCROLLSAWWORKSHOP.BLOGSPOT.COM

Digital Patterns Designed by Steve Good



Hundreds of free Patterns Stencil Printer Jigsaw Puzzle Templates DVD's Key Chain Pattern Printer Video Tutorials Reviews Community Forum and more.

If you would like to donate click here. No Paypal account needed.

Pav Pal



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

VISA

Copyright Steve Good 2019

General Pattern Information

You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the "Page Sizing & Handling" section. Make sure the "Actual Size" is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the "Pages to Print" section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions




Actual size Shrink oversized pages	S <u>i</u> ze	Poster	Multiple	Booklet	
Shrink oversized pages Custom Scale: 100 Choose paper source by PDF page size Pages to Print Image: Image in the state of	🔿 Fit				
Custom Scale: 100 % Choose paper source by PDF page size All Current page	Actual size	◀			
Choose paper source by PDF page size All Current page) Shrink oversized	-			
 ● All ● Current page 	Custom Scale:	100 %			
© Current page	Choose paper s	ource by PDF page si		Print	
				-	
Dages 11 - 24					
O Pages 1-54			Pages	1 - 34	

Table Top Basketball Shooter








The 1/16" acrylic is difficult to cut on the scroll saw. I sandwich in between two sheets of plywood and get a perfect cut.

It's also best to drill the two holes for the screws before you remove the plywood. That will keep it from cracking.



Note the angle on the flipper stand. The pattern shows the side view of the block. Use that diagram to sand the angle on the block.

Use super glue and fixative to attach the string to the ping pong ball. I also use super glue on the knot to keep it secure.

