

SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM


Digital Patterns

Designed by Steve Good



Hundreds of free Patterns
Stencil Printer
Jigsaw Puzzle Templates
DVD's
Key Chain Pattern Printer
Video Tutorials
Reviews
Community Forum and more.

If you would like
to donate click
here. No Paypal
account needed.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

Copyright Steve Good 2017



General Pattern Information

You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the “Page Sizing & Handling” section. Make sure the “Actual Size” is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the “Pages to Print” section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.


Printing Instructions





This box was designed for my wife and I use my laser to engrave the saying. To make it a pattern for the blog I designed the alternate lid design blow.





Stack cut layer 1 and layer 3 together to save time.

Drilling holes for the dowels is a multi step process.

The dowels are 1/4" diameter and just long enough to fit through the lid and into the layer 1 without bottoming out. Use a 15/64" drill bit for a snug fit.


Gang the lid and layer 1 together when you drill the four holes.

You need to drill accurately because the lid and box need to line up.

Insert the dowels into the lid and round over the tips.

You will need to drive the dowels into the lid with a mallet. The round over allows the dowels to fall into the holes easier.

Now take a 9/32" drill bit and enlarger the holes in Layer 1. Enlarging the holes gives you some wiggle room to place the lid on the box.




Layer 1
Body layer
Layer 3
Bottom

Lid showing the locating dowels.

Finger indent.

Glue up all the layers and clamp to dry.
After the glue dries you need to sand everything flush.
Sanding is best done with a disk sander. Install the lid
while you sand so it get trued up also.
Glue on the lid decoration.
I used a spindle sander to sand the finger indent.
Do a finish sanding and apply the finish of choice.



Alternate lid decoration.
1/4" Thick

