

SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM

Digital Patterns

Designed by Steve Good



Hundreds of free Patterns
Stencil Printer
Jigsaw Puzzle Templates
DVD's
Key Chain Pattern Printer
Video Tutorials
Reviews
Community Forum and more.

If you would like
to donate click
here. No Paypal
account needed.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

Copyright Steve Good 2017

General Pattern Information



You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the “Page Sizing & Handling” section. Make sure the “Actual Size” is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the “Pages to Print” section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions



Page Sizing & Handling ⓘ

Size

Poster

Multiple

Booklet

☐ Fit

☒ Actual size

☐ Shrink oversized pages

☐ Custom Scale: %

☐ Choose paper source by PDF page size

Pages to Print

☒ All

☐ Current page

☐ Pages

▶ More Options


Fretwork Clock



HERITAGEWOOD.COM !

I used 1/4" Thick Baltic birch plywood for this clock.
You can buy this product from <http://www.heritagewood.com>

Parts Diagram



This is how I made the 45 degree miters on the roof peek. You can use any method you like they just need to be 45 degrees.




I used slot and tab for some of the parts. These can be tricky to get sized correctly when cutting them. It's best to slightly under cut then and file to fit.


Because then can be tricky I minimized their use. Some parts are simply glued during assembly. Glue is more than adequate to hold thos pieces.

I laid the back board down flat during assembly and added the sides, front, bottom, roof support, Left and right roof then ornamentation in that order.

Test fit the pieces before you add the glue.



Join pattern at the dotted lines to make full front pattern.



Requires a 2 3/4\" clock insert with a 2 3/8\" mounting hole.



[Link to the one I used](#)

A


Join with pattern on the
next page to make the
full back pattern.


1/4" Thick

Mount part J
here to support the
roof

A
Back


Hanging hole






Ornamentation

1/4" Thick



H



Roof Support



J is glued to the top of the back board
to help support the roof.

Side
B

1/4" Thick

Side
C

1/4" Thick



E

1/4" Thick

Bottom

