


SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM



Digital Patterns

Designed by Steve Good



Hundreds of free Patterns
Stencil Printer
Jigsaw Puzzle Templates
DVD's
Key Chain Pattern Printer
Video Tutorials
Reviews
Community Forum and more.

Click to Donate.



Scan to Donate



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevgood.com

Copyright Steve Good 2020

General Pattern Information



You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the "Page Sizing & Handling" section. Make sure the "Actual Size" is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the "Pages to Print" section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions



Page Sizing & Handling

Size

Poster

Multiple

Booklet

Fit

Actual size

Shrink oversized pages

Custom Scale: %

Choose paper source by PDF page size

Pages to Print

All

Current page

Pages

▶ More Options

Picture Tops







Spray the wood and the back of the picture for a permanent bond.


Center punch the center mark for accurate drilling.





Use a backer board. Line up the drill bit with the center punch. Place a front board. Drill the hole.

The front and back board will prevent tear out on the back and prevent the paper from ripping.



The front and back holes should be clean.





Carefully cut the octagon with the scroll saw.
I used an octagon to make it easier to cut.

Cut your dowel 5" to 5.5" long. I used 5/16" dowel.






Gently round over the tip of the dowel.

Glue the dowel in to the top. Be careful to keep the dowel 90 degrees to the top.




Apply a spray finish to protect the picture.



1/4" Thick



1/4" Thick



1/4" Thick



1/4" Thick




1/4" Thick




1/4" Thick



1/4" Thick



1/4" Thick



This is a blank that you can import into Inkscape and add your own pictures.

You can use the video at this link to learn how to apply a picture to the pattern above.

<https://youtu.be/t61SJNfhSxs>