SCROLLSAW WORKSHOP

Digital Patterns Designed by Steve Good









Hundreds of free Patterns Stencil Printer **Jigsaw Puzzle Templates** DVD's Key Chain Pattern Printer Video Tutorials Reviews Community Forum and more.





You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.


Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the "Page Sizing & Handling" section. Make sure the "Actual Size" is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the "Pages to Print" section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions





Glue bottle holder. Stop the glue bottle shake.




It never works out when you store your glue bottle on it's bottom. When you get ready to use it you have to shake like crazy to get the glue flowing. Then if your lucky the glue has not dried in the tip. It best to store the glue bottle upside down. This keeps the glue ready to flow. It also helps keep air out of the tip causing the glue to dry and clog things up.



Notice: I slightly modified the pattern after I built prototype. The legs were a little too tall so I shortened them by 1/2".

On the pattern there are two diameter holes for each position. The larger holes are better for round glue bottles. The smaller hole is better for the rectangular bottles. This holder works best with the round bottles.

I generally buy large bottles and pour it into smaller round bottles.



After you glue on the legs drill 15/64" holes at 1,2,3 and 4. Insert 1/4" wooden dowels through the top and into the legs.