

SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM

Digital Patterns

Designed by Steve Good



Hundreds of free Patterns
Stencil Printer
Jigsaw Puzzle Templates
DVD's
Key Chain Pattern Printer
Video Tutorials
Reviews
Community Forum and more.

If you would like
to donate click
here. No Paypal
account needed.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

Copyright Steve Good 2019



General Pattern Information

You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the “Page Sizing & Handling” section. Make sure the “Actual Size” is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the “Pages to Print” section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions






Small jewelry Tray

We will use a beveled relief cut to make the dish section of the tray.


Bottom View







To make a relief cut we need to set the blade at a small angle and make test cuts in the waste section of the board until we get the amount of relief we need. My first test cut was 4 degrees and a little too shallow. 3.5 degrees was fine.

With the angle set cut only the dish section.





When you complete the relief cut you can set the center sections aside. Set the blade back to 90 degrees and make the rest of the cuts.





This is what the tray should look like as cut.


This pictures show the amount of relief I got with the 3.5 degree tilt.






Here is the bottom of the tray.

I used a round over bit to ease all the edges. If you do not have a router sand the edges well.





When you glue in the dish part to the rest of the tray use as little glue as possible and apply it to the bottom edge of the tray. You will still have some glue cleanup to do on the bottom.

1/2" Thick

