## SCROLLSAWWORKSHOP.BLOGSPOT.COM

## Digital Patterns Designed by Steve Good



Hundreds of free Patterns Stencil Printer Jigsaw Puzzle Templates DVD's Key Chain Pattern Printer Video Tutorials Reviews Community Forum and more.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires. steve@stevedgood.com Copyright Steve Good 2015

## Wireless Desk Lamp



The project requires a LED puck light. I bought this set of three at Lowes. This pattern requires a puck that is 2.75" in diameter.






The lamp neck is adjustable to point the light where it is needed.

The LED puck is stuck into the shade using the two sided tape included in the package.





Lay out all the parts on the wood blanks. Drill the 1/4" holes in the neck and the shade brackets.

Round over the neck and outside of the base. Glue the neck into the base.

Glue the shade to the shade circle.

I used threaded rod and wing nuts but you can use a bolt and nut if available.





Glue the shade brackets into the shade. Do your finish sanding and apply your finish.

## Attache the shade to the nect with the threaded rod and wing nuts.



Tape the LED puck into the shade.

