

# SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM

## Digital Patterns

Designed by Steve Good



Hundreds of free Patterns  
Stencil Printer  
Jigsaw Puzzle Templates  
DVD's  
Key Chain Pattern Printer  
Video Tutorials  
Reviews  
Community Forum and more.

If you would like  
to donate click  
here. No Paypal  
account needed.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

Copyright Steve Good 2018

# General Pattern Information



You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at [steve@stevedgood.com](mailto:steve@stevedgood.com)

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the “Page Sizing & Handling” section. Make sure the “Actual Size” is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the “Pages to Print” section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

## Printing Instructions



### Page Sizing & Handling ⓘ

Size

Poster

Multiple

Booklet

☐ Fit

☒ Actual size

☐ Shrink oversized pages

☐ Custom Scale:  %

☐ Choose paper source by PDF page size

### Pages to Print

☒ All

☐ Current page


☐ Pages

▶ More Options




Small Vanity Mirror






Acrylic mirror. Cut between two pieces of Baltic Birch plywood. Keep the protective film on the mirror until it is installed in the frame.

Stack cut the front and back of the frame.  
Cut the exterior of both pieces first.







Separate the front and back of the frame and cut out the interior of the front of the frame.

Make sure the mirror fits the cut out.







I used 1/4" diameter dowel rod for the pivot. This is just a friction fit so you want the dowel snug in the holes drilled in the stand. You may need to use a smaller bit and sand the dowels to a snug fit.

The dowels are pushed through the stand holes and glued in to the frame. The hole in the frame is just deep enough to accept the dowel and glue.


Drill the holes carefully. If they are not parallel to the frame the mirror will not sit straight in the stand.

Round over all the edges with a router.  
If you do not have a router then sand  
a nice contour around the edges.






1/4" Thick




Hole drilling guideline.





Acrylic  
Mirror

Sandwich the mirror  
between two pieces of  
Baltic birch plywood  
and cut to shape.



Base 1/2" Thick