

SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM

Digital Patterns

Designed by Steve Good



Hundreds of free Patterns
Stencil Printer
Jigsaw Puzzle Templates
DVD's
Key Chain Pattern Printer
Video Tutorials
Reviews
Community Forum and more.

If you would like
to donate click
here. No Paypal
account needed.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

Copyright Steve Good 2017



General Pattern Information

You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the “Page Sizing & Handling” section. Make sure the “Actual Size” is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the “Pages to Print” section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions



Sprint Car from a 2 X 4.



This toy is not recommended for children who still put small parts in their mouth.



Your source for scroll saw ready boards.



I used a construction grade 2" X 4" for all the parts except the wheels. The wheels were purchased separately. You can buy the wheels from many online sources. Here is a link to one source.









<https://www.bearwood.com/product1405.html>

Warning. I used the table saw to dimension the boards to 1/2" and 1/8" thicknesses. This type of cut can be dangerous. If you are not comfortable with making this cut then use pre-dimensioned wood for the thinner parts.



Part assembly diagram.





1 1/2" diameter wheels
1/2" Thick

You will need two 1/4" diameter dowels
for the axles. The need to be ~ 2 1/4"
Long