

# SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM

## Digital Patterns

Designed by Steve Good



Hundreds of free Patterns  
Stencil Printer  
Jigsaw Puzzle Templates  
DVD's  
Key Chain Pattern Printer  
Video Tutorials  
Reviews  
Community Forum and more.

If you would like  
to donate click  
here. No Paypal  
account needed.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevedgood.com

Copyright Steve Good 2017



## General Pattern Information


You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at [steve@stevedgood.com](mailto:steve@stevedgood.com)

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the “Page Sizing & Handling” section. Make sure the “Actual Size” is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the “Pages to Print” section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

## Printing Instructions







HERITAGEWOOD.COM !

Your source for scroll saw ready boards.



I used Zebra wood for the main body front.  
Cherry for the main body back,  
Hard maple for the top, bottom and tree.

Prepare the wood and the pattern. You can cut the  
clock insert hole with a forstner bit or with your  
scroll saw. Either way use the pattern for a template.



I used the [www.bearwood.com](http://www.bearwood.com) 2 3/4" clock insert.







I used the forstner bit for the clock insert hole.





Cut the two boards to size and glue them together.






Line up the boards well and clamp.





While waiting for the glue to dry cut the tree ornamentation





Once you have the main body of the clock sanded flush on all sides it's time to glue on the top and bottom. Clamp well and let the glue dry.

Sand the top and bottom flush with the main body.






Glue on the tree ornamentation.


Finish the project with a clear finish.

Insert the clock insert.






3/4" Thick







1" Thick



1/4" Thick



1/4" Thick