

SCROLLSAW WORKSHOP

WWW.SCROLLSAWWORKSHOP.BLOGSPOT.COM

Digital Patterns

Designed by Steve Good



Hundreds of free Patterns
Stencil Printer
Jigsaw Puzzle Templates
DVD's
Key Chain Pattern Printer
Video Tutorials
Reviews
Community Forum and more.

If you would like
to donate click
here. No Paypal
account needed.



Note to commercial print employees: I give my permission to print as many of this pattern book as your customer requires.

steve@stevetgood.com

Copyright Steve Good 2017



General Pattern Information



You may use this pattern to make as many of the project as you like. You are free to use any technique including mass production to build the project. The pattern may be copied and given to others provided the entire book is kept intact. You may not sell the pattern or include it in another commercial package of any type.

Steve Good retains the right to the pattern. If you have any questions about the use of this pattern please contact me at steve@stevedgood.com

When printing this pattern it is important to print it full size. When you bring up the print dialog box look in the “Page Sizing & Handling” section. Make sure the “Actual Size” is selected before you hit print.

You also only need to print the page/s you need. After the print dialog opens look for the “Pages to Print” section. You can print the current page or a range of pages. This will help save ink by not printing the title/instruction pages.

Printing Instructions



Scroll Saw Bowl



HERITAGEWOOD.COM !

Your source for scroll saw ready boards.
www.heritagewood.com




Prepare the wood blank 8" X 8" X 1/2" thick

I like to make scroll saw bowls that have thin walls. I usually shoot for about 1/8" thick when completely sanded. To accomplish this I start with rings that are 1/4" thick.


This pattern is designed to make a bowl that is ~ 7 inches in diameter with ~ 1/8" thick walls.


The time invested in sanding is what makes this project. You will need some power sanding tool to make this project.



We will now determine the angle we need to set the saw. The rings of this bowl pattern are 1/4" wide. Draw two lines on the edge of the board 1/4" apart.


Lay the board on the saw table and adjust the tilt until the blade goes from the top left corner to the bottom right corner of the two lines drawn above.





We need to drill the holes at the same angle that the table is tilted. Cut a board on the saw and use it as a guide to start the holes.

Cut each ring at the angle indicated above.






When you reverse stack the rings they will form a bowl.





Carefully glue each ring together. Do not glue on the bottom until after we sand the bowl interior. It's easier to sand if the bottom is not attached.






Use power and hand sanding to smooth out the exterior and interior of the bowl. This takes some time but the better the job you do sanding the better the bowl will look.

After you get it all sanded smooth, glue on the bottom and sand it flush with the walls.

Depending on how you plan to use the bowl use the appropriate finish.

1/2" Thick



This will make a bowl that is ~ 3.5" tall and a 7" diameter.